

Vive Tracker FAQ

Type	No.	Question	Answer
Common	1	How do I connect the dongle to my computer?	Connect one end of the supplied USB cable to the dongle cradle, and then attach the dongle to the cradle. Connect the other end of the USB cable to your computer.
	2	How do I charge Vive Tracker?	While in VR, you can check the battery level of Vive Tracker when no apps are running, or when the System Dashboard is up. When the battery is low, the indicator will show a single red dot. Make sure to use the USB cable that's in the box. Connect the USB cable to the power adapter that came with your Vive controllers, and then plug the power adapter to a power outlet to charge Vive Tracker. You can also connect Vive Tracker to a computer's USB port to charge it. When Vive Tracker is fully charged, its status light either shows white if it is off or green if it is turned on.
	3	How do I pair the dongle with Vive Tracker?	1. Turn on HMD and pair with 2 controllers 2. Connect dongle to your computer 3. Turn on Vive Tracker to have the pairing process is finished automatically Warning: If Vive Tracker cannot be automatically paired the first time, the dongle may pair with another equipment. To manually pair Vive Tracker, open the SteamVR app, tap the down arrow, and then select Devices > Pair Controller. Follow the on-screen instructions to complete the
	4	What does the status light on Vive Tracker mean?	The status light shows: <ul style="list-style-type: none"> • Green when Vive Tracker is in normal mode • Blinking red when battery is low • Blinking blue when Vive Tracker is pairing with the headset or dongle • Blue when Vive Tracker is connecting with the headset or dongle • Orange when charging
	5	How can I update Vive Tracker?	1. From your computer, open the SteamVR app. 2. Using the supplied USB cable, connect the Vive Tracker to one of your computer's USB ports. The firmware update will start automatically once tracker is detected by the SteamVR Warning: Do not unplug the micro-USB cable any time before the firmware update is complete. Doing so could result in a firmware error.
	6	Why does Vive Tracker automatically turn off?	When Vive Tracker turns off, some of the possible reasons might be: <ul style="list-style-type: none"> • The battery is drained • Pairing has timed out after being idle for more than 30 seconds • There was no user movement for 5 minutes
	7	Can I use more than one Vive Tracker?	Multiple Vive Tracker hardware can be used, but limitations apply.
	8	Why can't I see Vive Tracker on SteamVR?	Check that your SteamVR app is the latest version.
	9	How do I reset Vive Tracker?	To reset Vive Tracker, connect it to your computer using the supplied USB cable, and then press and hold the Power button for 10 seconds.
	10	How many Tracker can be adapted?	The maximum number of tracking objects can be adopted is 11 pcs of Vive Tracker plus 2 pcs of Vive controller.

Type	No.	Question	Answer
SDK	1	How do identify whether Vive Tracker or the controller is being tracked?	You can use the class type of SteamVR SDK to identify if Vive Tracker or the controller is currently being tracked.
	2	Does Vive Tracker have a different coordination system compared to the controllers?	Yes. Content developers need to apply different coordination settings based on the position where the Vive Tracker is mounted.
	3	How can I replace the controller with Vive Tracker if I already created content meant for the controller?	Content developers need to apply different coordination settings based on whether Vive Tracker is mounted on the same position as the controller. If its position is different, content developers need to recalibrate for Vive Tracker.
	4	What's the equivalent of Vive Tracker's hardware button to the controller?	The hardware button of Vive Tracker maps to the System button of the controller.
	5	How can I simulate the button event when I connect Vive Tracker to a computer through USB?	Check the "Data format" section in the developer guidelines, and follow the SetFeature 0xB4 format to fill your simulated data in "Button byte" data.
	6	How can I simulate the controller trackpad when I connect Vive Tracker to a computer through USB?	Check the "Data format" section in the developer guidelines, and follow the SetFeature 0xB4 format to fill your simulated data in "Pad X" and "Pad Y" byte data.
	7	Why is tracking lost when I connected Vive Tracker to a USB cable?	When you connect Vive Tracker to your computer using a USB cable, it enters data sending mode. To resume tracking while connected to a USB port, follow the developer guidelines to send the SetFeature 0xB3 command to fill Host type byte.
	8	Can we implement our own data into Vive Tracker's data	Vive Tracker only supports data that's compatible with the controllers.

Type	No.	Question	Answer
Hardware	1	Can I customize the POGO pins?	Yes, you can. For information on how to customize the POGO pins, contact www.vive.com/us/support/contactus .
	2	What's in the downloadable 3D CAD file for the Vive Tracker?	The 1.77KB ZIP file contains the .IGS and .STP for Vive Tracker. It's not a requirement to use the files, but it can help if you have 3D modeling software.